

Slider Frame & Doors Assembly Instructions.

Door Fitting. Start by using end doors

1. Place the door onto the bottom track.



2. Push door upright and slide the overhead Bracket into the top corner of the door.

Then lift the door clear of the bottom track and tighten the screws.



4. Check the brush seals against the frame. and moves smoothly.