



## Electrical Frame Connection

**Please connect mains supply 230v to terminals**




220 /240v  
Earth  
Neutral



Light Switch

## To connect LT doors



To connect side door,  
Place hinge pin in next hole  
to allow more space when  
connecting.

## Make the electrical connections

Push connections into frame.

Place cover fasteners into position then 1/4 turn to fix